



SÜBR BOTTLING & STORAGE GUIDELINES







PROCESSING

- Store closures one day before usage at 18-20°C / 64-68° F
- Bottle finish in compliance with EN 12726 or CE.T.IE. GME 50.01 (non-standard finishes require a bottling trial)
- · Corker must be in perfect working condition
- Corker jaws must be checked before and during use for damages
- Plunger must be centered
- Due to the high compressed head space under inner seals the use of a vacuum pump or flushing of the head space with CO₂ is recommended

25°C OK 5°C

AFTER BOTTLING

Store in a dry, ventilated and odor free environment



